
ARTICLE

Development of contamination estimation method for PWR

Tomohiro Ogata^{a*}, Takashi Muramatsu^a, Koichi Yoshisako^a, Kenichiro Kino^b, Masakazu Matsuura^c,
Toshinobu Katsumi^c, Tetsuo Noyori^c and Hiroataka Iduka^d

^aMitsubishi Heavy Industries, Ltd., 1-1-1 Wadasakicho, Hyogo-ku, Kobe, Hyogo-ken, 652-8585, Japan; ^bNuclear Development Corporation, 622-12 Funaishikawa, Tokaimura, Ibaraki-ken, 319-1111, Japan; ^cKansai Electric Power Co, Inc., 13-8 Goichi, Mihama-cho, Mikata-gun, Fukui-ken, 919-1141, Japan; ^dKanden Power-Tech Corp., 1-2-1-1800 Benten, Minato-ku, Osaka, Osaka-fu, 552-0007, Japan

Accurate estimation of radioactive inventory is essential for nuclear power plant, since it effects on nuclide screening for clearance, disposal cost, collective dose and public exposure estimation. This paper describes contamination estimation method. Authors have developed contamination estimation method for PWR primary circuit and other systems. The method is based on the assumption that only particulates in the coolant are responsible for contamination and S. K. Beal's theory of particle deposition and erosion model. There are various contamination calculation conditions and some of them, such as failed fuel fraction, are difficult to determine with plant design data and thus measured data of radioactive waste generated from the existing plant is used for estimating fission products contamination. Contamination estimation results are in good agreement with the measured data. For the application of this method to the contamination density estimation for the PWR operational waste and for decommissioning, the improvement of estimation accuracy will be required by conducting further data accumulation regarding the plant operating data and accurate plant design parameters.

Keywords: *contamination; residual activity; decommissioning; clearance*

1. Introduction

It is important to estimate radioactive inventory of nuclear power plant for new reactor licensing, decommissioning planning, cost and collective dose and public exposure estimation. Results of this estimation are also used for radioactive inventory for the nuclides screening in clearance.

Residual activity consists of induced activity and contamination activity. Induced activity estimation method is well established by using neutron transport calculation codes (DORT [1], etc...) and activation calculation codes (ORIGEN2 [2] series etc...). Due to the complexity of representing the movement of corrosion product (CP), fission product (FP) and actinide in the primary circuit and the other systems, the contamination estimation method is not established.

There are some contamination estimation codes, e.g. ACE-II [3], which target primary circuit other than Reactor Heat Removal System (RHRS) and Waste Disposal System (WDS) etc..

Mitsubishi Heavy Industries, Ltd. (MHI) has been developing contamination estimation method to estimate residual activity of nuclear power plant at the end of the

plant life. It treats CPs, FPs and actinides and covers Reactor Coolant System (RCS), Chemical and Control Volume System (CVCS), RHRS, Spent Fuel Purification and Cooling System (SFPCS) and other components. This paper shows estimation methodology of CPs, FPs and actinides contamination in PWR systems considering the fuel defect.

2. Contamination estimation method

2.1. Assumption

Contamination estimation conditions are assumed as follows:

- Only particulates contribute to deposition on the inner surface of the piping and components although nuclides are particulate or ionic state in the coolant.
- Source terms are activated CPs irradiated at reactor core, FPs released from fuel surface and fuel defect.
- Radioactivity of FP is determined by FP/CP activity ratio measured in the radioactive waste generated from the existing plant.
- Modeling of deposition and erosion of the

*Corresponding author. Email: tomohiro_ogata@mhi.co.jp

particulate is based on S. K. Beal's [4,5] theory.

- With regard to components which are difficult to be applied to Beal's theory, such as a tank with accumulated fluid, contamination density is estimated by gamma ray measurement result and dose to contamination conversion factor.

2.2. Source terms

2.2.1 Activated corrosion products

CPs in the vicinity of the reactor core is activated by neutron irradiation. Source term of the activated CPs is determined by assumed metal abundance on fuel rods, neutron flux at the reactor core and average irradiation time of the operating cycle with ORIGEN2.

2.2.2 Fission products from fuel contamination

Fuel rods surface have manufacturing contamination of UO₂ and it produces FPs by neutron irradiation at the reactor core. Source term of FPs produced by the fuel surface contamination is determined by assumed irradiation time, burn up, neutron flux at the reactor core and the regulated surface contamination value at the manufacturing of a fuel with ORIGEN2.

2.2.3 Fission products from fuel defect

Source term of FPs produced by the fissioning of the fuel is determined by assumed neutron flux at the reactor core, burn up and irradiation time with ORIGEN2.

2.3. Contamination estimation model

2.3.1 Reactor Coolant System (RCS)

Contamination of the components and piping in the RCS is caused by particulate radionuclides released from the reactor core. Deposition and erosion of particulate radionuclides are modeled with S. K. Beal's theory and particulate radionuclide concentration in the coolant and deposited activity are calculated by the following equations considering particulate activity balance between the fluid and wetted surface.

$$\frac{dC_i}{dt} = \frac{S_i \times R_i \times m_i}{V} - \left\{ \lambda_i + K_d \times \frac{SU}{V/\rho} + \frac{Q}{V} \left[1 - \frac{1}{DF_i} \right] \right\} \times C_i + B_i \times E \times \frac{SU}{V} \quad (1)$$

and

$$\frac{dB_i}{dt} = \rho \times K_d \times C_i - (\lambda_i + E) \times B_i \quad (2)$$

where,

C_i: Nuclide i particulate concentration in coolant (Bq/g)

S_i: Source term of nuclide i (Bq)

R_i: Fission product escape rate coefficient (1/s)

m_i: Particulate rate of nuclide i in reactor coolant (-)

V: Weight of reactor coolant (g)

λ_i: Decay constant of nuclide i (1/s)

K_d: Deposition coefficient in RCS (cm/s)

SU: Wetted surface area of RCS (cm²)

ρ: RCS coolant density (g/cm³)

Q: CVCS purification flow rate (g/sec)

DF_i: Demineralizer isotopic decontamination factors (-)

B_i: Deposited density of nuclide i (Bq/cm²)

E: Erosion rate constant in RCS (1/s)

2.3.2 Chemical and Volume Control System (CVCS)

Radioactive particle deposition mechanism in CVCS is the same as that in RCS. Rate of increase of deposited activity at downstream of the demineralizer is given mathematically by the following activity balance equation. Here, radioactive concentration in the coolant of the upstream of the demineralizer is supposed to be the same as RCS concentration.

$$\frac{dB_i}{dt} = \rho \times K_d \times \frac{C_i}{DF_i} - (\lambda_i + E) \times B_i \quad (3)$$

2.3.3 Residual Heat Removal System (RHRS)

RHRS is operated at the time of plant startup and shut down. Radioactive concentration in the coolant of RHRS changes because RHRS operation condition, such as pH and temperature, changes with time. Rate of increase of deposited activity of the RHRS is expressed as equation (4). Radioactive concentration in the coolant of RHRS is given by the measured value of the existing plant. **Figure 1** shows particulate Co-60 concentration in RHRS coolant change at RHRS operation. In this study, changes of coolant activity of each nuclide are represented by change of the particulate Co-60 concentration in RHRS because it is difficult to measure other nuclides.

$$\frac{dB_i}{dt} = \rho \times K_d \times C_i - (\lambda_i + E) \times B_i \quad (4)$$




Figure 1. Co concentration change at typical RHRS operation

2.3.4 Spent Fuel Pit Cooling System (SFPCS)

SFPCS cools down and purifies the Spent Fuel Pit (SFP) water and reactor cavity coolant water at the time of reactor shut down.

Source term of the SFPCS is radionuclides eroded from the deposited radionuclides on the spent fuels. Equation (5) shows gradient of radioactive particulate of nuclide i concentration in SFPCS coolant. Deposited activity is given by equation (6).

$$\frac{dC_i}{dt} = \frac{S_0 \times m_i}{V_{SFP}} - C_i \left\{ \frac{Q_{SFP}}{V_{SFP}} \left(1 - \frac{1}{DF_i} + \eta \right) + \frac{S}{V_{SFP}} K_d - \lambda_i \right\} + B_i \times E \times \frac{S}{V_{SFP}} \quad (5)$$

and

$$\frac{dB_i}{dt} = \rho \times K_d \times \frac{C_i}{DF_i} - (\lambda_i + E) \times B_i \quad (6)$$

Where,

S₀: Particulate release rate from fuel assembly (Bq/s)

V_{SFP} : Mass of SFPCS coolant (cm^3)
 Q_{SFP} : SFPCS purification flow rate (cm^3/s)
 η : Filtration efficiency (-)
 S : Wetted surface of SFPCS (cm^2)

2.3.5 Waste disposal system and other components

A tank which is not operated on a continuous basis, such as spent resin storage tank (SRST) of WDS, is not always in contact with the moving fluid and there is accumulated fluid in the tank. It is difficult to apply S. K. Beal's theory to the components with accumulated fluid because S. K. Beal's theory is for the particle in the flow.

Contamination density of WDS and other components are estimated by gamma ray measurement result and dose to contamination conversion factor, which is prepared in advance. Conversion factor is calculated by point kernel code QAD-CGGP2R [6]. Nuclide composition of WDS and other components is assumed to be the same as that of RCS in this calculation.

2.4. Fuel defect consideration

2.4.1 Fuel defect reflection on the source terms

It is known that concentrations of alpha-nuclides become high in the coolant after fuel defect. Effect of the fuel defect needs to be considered. **Figure 2** shows basic concept of the fuel defect effect on the coolant concentration and the source terms.

Alpha-nuclides are released by fuel defect and concentration of alpha-nuclides decreases with time due to the CVCS purification. In order to simulate change of alpha-nuclides in the coolant, alpha-nuclides/Co-60 ratio of the source term is corrected by the measured alpha-nuclides/Co-60 concentration ratio of CVCS letdown filters in the considered plant. Alpha-nuclides/Co-60 ratio of the CVCS letdown filters represents fuel defect effect in the coolant for a long term period because alpha-nuclides are released into the coolant by the fuel defect and Co-60 concentration in the coolant is almost constant regardless of the fuel defect.




Figure 2. Modeling of source term with fuel defect

2.4.2 Fuel defect reflection on contamination

Reflecting the measured alpha-nuclides/Co-60 ratio of coolant filter on source term is not sufficient to estimate absolute contamination density value of FPs and actinides. Measured Cs-137/Co-60 of the radioactive waste generated from the considering plant is introduced to meet the measured FPs and actinides data (**Figure 3**). Contamination density of FPs is corrected by multiplying Cs-137/Co-60 ratio. Cs-137/Co-60 ratio is

used for the correction because of the following three reasons: (i) Cs-137 represents FP and is easier to be measured than the other nuclides of FP, (ii) Co-60 represents CP and is easy to be measured, (iii) calculated contamination density of Co-60 is consistent with measured data.

3. Contamination estimation

Contamination estimation is carried out for the model plant. **Table 1** and **Table 2** show source term evaluation condition and contamination estimation condition, respectively.

Figure 4 shows comparison between calculated results of Mn-54/Co-60 ratio and measured Mn-54/Co-60 ratio of the radioactive waste generated from considered plant. And **Figure 5** shows comparison of Cs-137/Co-60 ratio between calculation and measurement, and specifies that both estimated CPs and FPs concentration are in good agreement with the measured data.




Figure 3. FPs density fitting to the measured data

Table 1. Source term estimation condition

Source term	Parameter	Source
CP	Amount of CRUD at core	Calculated by plant data
	CRUD composition	SUS304 and Inconel 690
	neutron flux at the core	Plant design data
FP/ actinides	Bun-up and specific power	Plant design data
	Irradiation time of a cycle	13 months operation
	Cooling time of a cycle	45 days outage
	Fuel composition	ORNL/TM-6051 [7]
	U-235 enrichment	Plant design data
	U amount	Plant design data
	UO ₂ contamination at fuel surface	JEAG 4204-2009 [8]

Table 2. Contamination estimation condition

Parameter	Source
Reactor coolant mass and density	Plant design data
Wetted surface area	Plant design data
CVCS purification factor	Plant design data
Deposition/erosion coefficient	Calculated by Beal's theory
Particulate fraction of nuclide	Measured and estimated data
Release rate of CP from the core	Erosion factor at reactor core
Escape rate of FP by the fuel defect	WAPD-TM-29 [9]
Release rate of FP from fuel surface	Derived from erosion factor
FP/CP ratio	Measured data




Figure 4. Calculation result of Mn-54/Co-60




Figure 5. Calculation results of Cs-137/Co-60

4. Nuclides screening for the clearance

Nuclides screening for the clearance is carried out based on the contamination calculation results of regulated 33 nuclides in Japan. Nuclides screening method is in compliance with Atomic Energy Society of Japan standard [10]. **Table 3** shows nuclides screening result. 10 nuclides, so-called “major nuclides” such as Co-60 and Cs-137 etc., are identified.

There is no variation of the calculated results because input parameters are nominal value of the plant design data because it is difficult to determine variation of all plant design data, and thus variation of measured data is introduced in the screening of the nuclides for the clearance. In this screening, only measured variation of FPs is considered because measured CPs data (e.g. Mn-54) have small variation compared to measured FPs data (e.g. Cs-137). FPs variation is introduced by multiplying concentrations of FPs by 0.001 to 100000. **Figure 6** shows the result of nuclides screening with measured variation. Vertical axis is the summation of concentrations divided by clearance level ($\Sigma D/C$) and thick line is the criterion value for nuclides screening. The result is that nuclides to be considered obtained by screening with the variation are the same as that without the variation. This is because Co-60 is the dominant nuclide of 33 nuclides and Cs-137, the most dominant nuclide of FPs, is two digits lower than the Co-60 concentration. Even if FP concentration has some fluctuates, no influence is to be given on the nuclide screening.

5. Conclusion

Contamination estimation method for PWR has been developed. This method uses both design and measured data and can estimate RCS, CVCS, RHRS, SFPCS and other components. Contamination calculation results are consistent with measured data. In order to apply this method to the contamination estimation for the PWR operational waste and for plant decommissioning waste, the alpha-nuclides/Co-60 data and measured contamination data will be required.

Table 3. Nuclide screening result for the clearance

Nuclide	Clearance Level [Bq/g]	Attribution fraction to the dose equivalent (5years after reactor shutdown)				
		RCS	CVCS	RHRS	SFPCS	WDS
H-3	100	8.9×10^{-9}	7.5×10^{-9}	1.9×10^{-7}	4.7×10^{-6}	8.9×10^{-9}
Mn-54	0.1	2.1×10^{-3}	1.1×10^{-3}	9.1×10^{-4}	2.2×10^{-3}	2.1×10^{-3}
Co-60	0.1	9.8×10^{-1}	9.8×10^{-1}	9.8×10^{-1}	2.6×10^{-1}	9.8×10^{-1}
Sr-90	1	4.3×10^{-6}	5.2×10^{-6}	5.9×10^{-6}	1.7×10^{-4}	4.3×10^{-6}
Cs-134	0.1	6.1×10^{-4}	4.6×10^{-4}	3.8×10^{-4}	4.8×10^{-2}	6.1×10^{-4}
Cs-137	0.1	7.9×10^{-3}	9.6×10^{-3}	1.1×10^{-2}	6.2×10^{-1}	7.9×10^{-3}
Eu-152	0.1	6.7×10^{-5}	7.8×10^{-5}	8.6×10^{-5}	5.3×10^{-3}	6.7×10^{-5}
Eu-154	0.1	5.6×10^{-4}	6.2×10^{-4}	6.5×10^{-4}	4.5×10^{-2}	5.6×10^{-4}
Pu-239	0.1	2.8×10^{-5}	3.6×10^{-5}	4.1×10^{-5}	6.7×10^{-5}	2.8×10^{-5}
Am-241	0.1	8.5×10^{-6}	1.1×10^{-5}	1.2×10^{-5}	2.0×10^{-5}	8.5×10^{-6}
Subtotal		9.9×10^{-1}	9.9×10^{-1}	9.9×10^{-1}	9.8×10^{-1}	9.9×10^{-1}
Other nuclides		1.0×10^{-2}	1.0×10^{-2}	1.0×10^{-2}	1.0×10^{-2}	1.0×10^{-2}
Total		1.0	1.0	1.0	1.0	1.0




Figure 6. Nuclide screening with measurement variation

Acknowledgements

The authors wish to thank Mr. Kuroda and Mr. Saigusa for the helpful comments to prepare this paper.

References

- [1] W.A. Rhoades and R.L. Childs, *The DORT Two-dimensional Discrete Ordinates Transport Code System*, RSIC-CCC-484, Oak Ridge National Laboratory, (1989).
- [2] A.G. Croff, *ORIGEN2-A Revised and Updated Version of the Oak Ridge Isotope Generation and*

- Depletion Code*, ORNL-5621, Oak Ridge National Laboratory, (1980).
- [3] T. Nishimura and K. Kasahara, Improvement of Crud Behavior Evaluation Code (ACE), *Proc. 1998 JAIF Int. Conf. on Water Chemistry in Nuclear Power Plants*, Kashiwazaki, Japan, Oct. 13-16, 1998, (1998), pp.310-314.
- [4] S.K. Beal, Deposition of Particles in Turbulent Flow on Channel or Pipe Walls, *Nucl. Sci. Eng.* 40 (1970), pp. 1-11.
- [5] S.K. Beal, *The Effect of Erosion and Deposition on Sampling of Entrained Particles*, WAPD-TM-1014, Bettis Atomic Power Laboratory, (1972).
- [6] Y. Sakamoto and S. Tanaka, *QAD-CGGP2 and G33-GP: Revised Version of QAD-CGGP and G33-GP*, JAERI-M 90-110, Japan Atomic Energy Research Institute, (1990).
- [7] A.G. Croff, M.A. Bjerke, G.W. Morrison and L.M. Petrie, *Revised Uranium-plutonium Cycle PWR and BWR Models for the ORIGEN Computer Code*, ORNL/TM-6051, Oak Ridge National Laboratory, (1978).
- [8] Nuclear Standard Committee of Japan Electric Association, *Quality Control Guide for Nuclear Fuels Used in Nuclear Power Plants*, JEAG4204-2009, Japan Electric Association, (2009). [in Japanese]
- [9] P.W. Frank, K.H. Vogel and P. Cohen, *Radiochemistry of Third PWR Fuel Material Test X-1 Loop NRX Reactor*, WAPD-TM-29, U. S. Atomic Energy Commission, (1957).
- [10] Atomic Energy Society of Japan standard, *Monitoring for Clearance with Clearance Level*, AESJ-SC-F005: 2005, Atomic Energy Society of Japan, (2005). [in Japanese]
-